



1



Platzieren Sie die Unterdecke unter das Hängemattenzelt.

Place the underquilt under the hammock tent.


2



Schließen Sie die Schnallen an beiden Enden der Unterdecke, um sie mit dem Hängemattenzelt zu verbinden. (Siehe **blaue** Markierung in der Abbildung).

Close the buckles at both ends of the underquilt to connect it to the hammock tent. (See **blue** marking in the illustration).


3



Das Seil an beiden Enden festziehen. (Siehe **grüne** Markierung im Bild).

Tighten the rope at both ends. (See **green** marking in the illustration).


4



An der Unterdecke befinden sich 4 Schnallen und im Hängemattenzelt 4 kurze Gurtbandschlaufen (siehe **rote** Markierung im Bild). Die Schnallen durch die kurzen Gurtbandschlaufen fädeln.

There are 4 buckles on the underquilt and 4 short webbing loops in the hammock tent (see **red** marking in the picture). Thread the buckles through the short webbing loops.

5



Die elastischen Gurtbänder an beiden Enden der Unterdecke mit den Karabinerhaken am Hängemattenzelt verbinden. Die Schnüre an beiden Enden nach Bedarf festziehen.

Connect the elastic webbing straps at both ends of the underquilt to the snap hooks on the hammock tent. Tighten the cords at both ends as required.